

ANDROS

ANDROS

Műszaki jellemzők

Összetétel: 65% ÚJRAHASZNOSÍTOTT POLIÉSZTER, 18% POLIÉSZTER, 8% MODAKRIL, 5% POLIAMID, 4% ÚJRAHASZNOSÍTOTT PAMUT.

Szélesség: 140 cm. UNE EN 1773

Súly m²: 574 gr/m²

Szakítószilárdság: >20N (BS4303) – >3 (DIN 53859-5)


Szakítószilárdság: >(ISO13934-1)

A varrat elmozdulása: < < 6 (DIN53868) – 4 (BS 3320) – 6 (DIN53868)

Kopásállóság: UNE EN ISO 12947

Pilling ellenállás: (5 max. 5) nincs pilling (ISO DIS 12945-2)






ANDROS_109

ANDROS_110

ANDROS_111

ANDROS_1266




ANDROS_127

ANDROS_1271

ANDROS_130

ANDROS_1302




ANDROS_1324

ANDROS_1357

ANDROS_1407

ANDROS_153




ANDROS_160

ANDROS_193

ANDROS_2047

ANDROS_209




ANDROS_210

ANDROS_211

ANDROS_2266

ANDROS_227




ANDROS_2271

ANDROS_230

ANDROS_2324

ANDROS_2330




ANDROS_2347

ANDROS_2357

ANDROS_253

ANDROS_260




ANDROS_271

ANDROS_293

ANDROS_300

ANDROS_347



ANDROS_51

ANDROS_56

ANDROS_90

The color of the displayed images may not correspond to the final product. Please consult your furniture store.

maintenance

For normal sofa maintenance we recommend that you vacuum the entire surface area regularly. You can use a normal home vacuum cleaner with a brush fitting.

water cleaning in three simple steps

Aquaclean[®] Technology enables you to get rid of small stains such as wine, coffee, food and even most marker pens without having to wash with soap or detergent.



Read the QR to find out more about the Aquaclean[®] cleaning method.

- 1 Remove any excess residue from your upholstery.
- 2 Apply water* over the stain, either directly or using a damp cloth, then wait a few seconds.
- 3 Finally, press down with the damp cloth and rub gently over the fabric in circular movements. If the stain does not come off completely (*especially dried in stains*) repeat the process as required.

*To avoid potential limescale stains, it is preferable use bottled water.

washing instructions

For normal care, you don't need to remove and wash the sofa fabric. But for large or tough stains, before washing review the following instructions:

maintenance and cleaning

liquids or oils

Absorb the excess liquid or oil with a cloth or paper towel, then rub gently with circular movements.

grease, pen ink

Apply water over the stain, either directly or using a damp cloth, leave on the fabric for a few seconds, then rub the stain gently with circular movements. Repeat the process as many times as necessary. Always leave the fabric to dry.

dust

Remove the dust with a vacuum cleaner.



Thanks to SafeFront[®] technology, our fabrics are protected against viruses and bacteria. They have been proven to reduce viral activity by over 91% after two hours of continuous contact.