

SOUSEL

Caracteristici tehnice

Compoziție: 97% POLIESTER, 3% BUMBAC

Lățime: 140 cm. UNE RO 1773

Greutate m2: 514 gr/m2

Rezistență la rupere: > 20N (BS 4303) – > 3 (DIN 53859-5)

Rezistență la tracțiune: > 350N (ISO 13934-1)


Deplasarea cusăturilor: < 4 (BS 3320) – < 6 (DIN 53868)

Rezistență la abraziune: 50000 cicluri UNE EN ISO 12947


Rezistență la pilling: 5 (5 max) f?r? pilling (ISO DIS 12945-2)

Rezistență colorantului la frecare: 5 (5 max) bun? (ISO 105-X12)







SOUSEL_10




SOUSEL_30




SOUSEL_300




SOUSEL_305




SOUSEL_314




SOUSEL_32




SOUSEL_321




SOUSEL_324




SOUSEL_336



SOUSEL_348



SOUSEL_349




SOUSEL_395




SOUSEL_51




SOUSEL_56




SOUSEL_60




SOUSEL_700




SOUSEL_710



SOUSEL_790



SOUSEL_795



SOUSEL_90

The color of the displayed images may not correspond to the final product. Please consult your furniture store.

maintenance

For normal sofa maintenance we recommend that you vacuum the entire surface area regularly. You can use a normal home vacuum cleaner with a brush fitting.

water cleaning in three simple steps

Aquaclean[®] Technology enables you to get rid of small stains such as wine, coffee, food and even most marker pens without having to wash with soap or detergent.



- 1 Remove any excess residue from your upholstery.
- 2 Apply water* over the stain, either directly or using a damp cloth, then wait a few seconds.
- 3 Finally, press down with the damp cloth and rub gently over the fabric in circular movements. If the stain does not come off completely (*especially dried in stains*) repeat the process as required.

Read the QR to find out more about the Aquaclean[®] cleaning method.

*To avoid potential limescale stains, it is preferable use bottled water.

washing instructions

For normal care, you don't need to remove and wash the sofa fabric. But for large or tough stains, before washing review the following instructions:

maintenance and cleaning

liquids or oils

Absorb the excess liquid or oil with a cloth or paper towel, then rub gently with circular movements.

grease, pen ink

Apply water over the stain, either directly or using a damp cloth, leave on the fabric for a few seconds, then rub the stain gently with circular movements. Repeat the process as many times as necessary. Always leave the fabric to dry.

dust

Remove the dust with a vacuum cleaner.



Thanks to SafeFront[®] technology, our fabrics are protected against viruses and bacteria. They have been proven to reduce viral activity by over 91% after two hours of continuous contact.