

TOUCAN

Technické vlastnosti

Složení: 98 % POLYESTER, 2 % POLYAMID

Šířka: 140 cm. UNE EN 1773

Hmotnost m2: 442 gr/m2

Pevnost při trhání: > 20N (BS 4303) – > 3 (DIN 53859-5)

Pevnost v tahu: > 350N (ISO 13934-1)

Posunutí švu: < 4 (BS 3320) – < 6 (DIN 53868)

Odolnost proti oděru: 35000 cyklů UNE EN ISO 12947

Odolnost proti žmolkování: (max. 5) bez žmolkování (ISO DIS 12945-2)

Odolnost barvy v průběhu času: 5 (max. 5) dobrá (ISO 105-X12)

Stálost barev na světle: 5 dobrá (ISO 105-B02)






TOUCAN_100

TOUCAN_13

TOUCAN_14

TOUCAN_156



TOUCAN_213

TOUCAN_245

TOUCAN_271

TOUCAN_300



TOUCAN_314

TOUCAN_316

TOUCAN_325

TOUCAN_373



TOUCAN_375

TOUCAN_383

TOUCAN_385

TOUCAN_387



TOUCAN_390

TOUCAN_395

TOUCAN_396

TOUCAN_51

The color of the displayed images may not correspond to the final product. Please consult your furniture store.

maintenance

For normal sofa maintenance we recommend that you vacuum the entire surface area regularly. You can use a normal home vacuum cleaner with a brush fitting.

water cleaning in three simple steps

Aquaclean[®] Technology enables you to get rid of small stains such as wine, coffee, food and even most marker pens without having to wash with soap or detergent.



Read the QR to find out more about the Aquaclean[®] cleaning method.

- 1 Remove any excess residue from your upholstery.
- 2 Apply water* over the stain, either directly or using a damp cloth, then wait a few seconds.
- 3 Finally, press down with the damp cloth and rub gently over the fabric in circular movements. If the stain does not come off completely (*especially dried in stains*) repeat the process as required.

*To avoid potential limescale stains, it is preferable use bottled water.

washing instructions

For normal care, you don't need to remove and wash the sofa fabric. But for large or tough stains, before washing review the following instructions:

maintenance and cleaning

liquids or oils

Absorb the excess liquid or oil with a cloth or paper towel, then rub gently with circular movements.

grease, pen ink

Apply water over the stain, either directly or using a damp cloth, leave on the fabric for a few seconds, then rub the stain gently with circular movements. Repeat the process as many times as necessary. Always leave the fabric to dry.

dust

Remove the dust with a vacuum cleaner.



Thanks to SafeFront[®] technology, our fabrics are protected against viruses and bacteria. They have been proven to reduce viral activity by over 91% after two hours of continuous contact.