

WIND

Technische Merkmale

Zusammensetzung: 56% POLYESTER, 34% RECYCELTE BAUMWOLLE, 10% BAUMWOLLE.

Breite: 140 cm. UNE EN 1773

Gewicht m2: 539 gr/m2

Reißfestigkeit: >20N (BS4303) – >3 (DIN 53859-5)

Zugfestigkeit: >350N (ISO13934-1)

Nahtverschiebung: <4 (BS 3320) – <6 (DIN53868)

Abriebfestigkeit: >50.000 Zyklen UNE EN ISO 12947

Pilling-Beständigkeit: 5 (5max) kein Pilling (ISO DIS 12945-2)






WIND-AC_01

WIND-AC_02

WIND-AC_100

WIND-AC_112




WIND-AC_12

WIND-AC_121

WIND-AC_13

WIND-AC_133




WIND-AC_134

WIND-AC_14

WIND-AC_153

WIND-AC_160




WIND-AC_213

WIND-AC_28

WIND-AC_29

WIND-AC_305




WIND-AC_309

WIND-AC_313

WIND-AC_315

WIND-AC_316




WIND-AC_321



WIND-AC_323




WIND-AC_324




WIND-AC_325




WIND-AC_336




WIND-AC_342




WIND-AC_347



WIND-AC_348



WIND-AC_349




WIND-AC_395



WIND-AC_407



WIND-AC_42



WIND-AC_430



WIND-AC_448



WIND-AC_514




WIND-AC_515




WIND-AC_516




WIND-AC_52



WIND-AC_521



WIND-AC_55



WIND-AC_60

WIND-AC_67

The color of the displayed images may not correspond to the final product. Please consult your furniture store.

maintenance

For normal sofa maintenance we recommend that you vacuum the entire surface area regularly. You can use a normal home vacuum cleaner with a brush fitting.

water cleaning in three simple steps

Aquaclean[®] Technology enables you to get rid of small stains such as wine, coffee, food and even most marker pens without having to wash with soap or detergent.



- 1 Remove any excess residue from your upholstery.
- 2 Apply water* over the stain, either directly or using a damp cloth, then wait a few seconds.
- 3 Finally, press down with the damp cloth and rub gently over the fabric in circular movements. If the stain does not come off completely (*especially dried in stains*) repeat the process as required.

Read the QR to find out more about the Aquaclean[®] cleaning method.

*To avoid potential limescale stains, it is preferable use bottled water.

washing instructions

For normal care, you don't need to remove and wash the sofa fabric. But for large or tough stains, before washing review the following instructions:

maintenance and cleaning

liquids or oils

Absorb the excess liquid or oil with a cloth or paper towel, then rub gently with circular movements.

grease, pen ink

Apply water over the stain, either directly or using a damp cloth, leave on the fabric for a few seconds, then rub the stain gently with circular movements. Repeat the process as many times as necessary. Always leave the fabric to dry.

dust

Remove the dust with a vacuum cleaner.



Thanks to SafeFront[®] technology, our fabrics are protected against viruses and bacteria. They have been proven to reduce viral activity by over 91% after two hours of continuous contact.